

The JAXIKIT

Deluxe Hand Bidet

The JAXIKIT includes:

- * ½" In-line Thermostatic Blending Valve
- * Panel mount Stop Valve / Hose Outlet
- * 1.25m Double Interlock Hose
- * Spray Head with sprung lever stop
- * Wall Bracket for Head

The interconnecting parts are not provided as these can be too varied.

The installation of the Jaxikit should only be attempted by tradesmen with plumbing skills. These instructions are only a guide.

The Blending Valve provided is a ½" BSP In-line valve with internal non-return valves and is intended to be positioned discreetly so easy access is all that is required. Once the temperature has been set adjustment is rarely necessary. A more expensive panel mount version of the Thermostatic Valve with Faceplate (ref, TBVC) is available if repeated adjustment is required.

It is advised that the mixed outlet pipe from the Thermostatic Valve should be firmly secured (not a flexible Hose) as this will give rigidity to the Stop Valve when in use.

The Stop Valve/Hose Outlet can be mounted on the panel and secured with a ½" backnut or threaded fitting depending on depth of panel. It is recommended the panel is not relied upon for stability but that the pipework and fittings provide rigidity.

In general use it is recommended that the Stop Valve is turned off after use to relieve the pressure in the Hose and reduce dripping. Occasionally it may be necessary to remove and soak the Head in descaling fluid.

GUIDE ILLUSTRATION

